



STEP3

Attach Base Bar (D) to L/R-Side Panel (A) & (F) with Screw(4).




STEP4

Place Stopper (E) onto each Cross Bar (E).



Recommended Maximum Weight



WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.



Assembly Instruction

Furinno Pine Solid Wood 4-Tier Bookshelf

MODEL: FNCL-33002

00:30


Approx. 30 minutes



Recomm. 2 Person



Tools Required



Customer Service

Tel/Fax: 281.500.9372





Toll Free: 773.299.8111 (Mon - Fri 9am - 5pm)







Email: support@furinno.com


www.furinno.com

 Find us on
Facebook



No	Hardware List	Qty
1	Wood Dowel 	24pcs
2	Socket Head Cap Screw 	16pcs
3	Hex Wrench 	1pcs
4	Screw 	12pcs

No	Parts List	Qty
A	L-Side Panel 	1pcs
B	Shelf Panel 	4pcs
C	Cross Bar 	4pcs
D	Base Bar 	2pcs
E	Stopper 	4pcs
F	R-Side Panel 	1pcs




USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

STEP1

- 1.1 Attach Shelf Panels(B) to L-Side Panel(A) and tighten with Socket Head Cap Screw(2) and Wood Dowel(1).
- 1.2 Attach Cross Bar(C) to L-Side Panel(A) and tighten with Screw(4) and Wood Dowel(1).



STEP2

- 2.1 Attach R-Side Panel (F) to Shelf Panel (B) and tighten with Socket Head Cap Screw(2) and Wood Dowel(1).
- 2.2 Tighten Cross Bar (C) to R-Side Panel (F) with Screw(4) and Wood Dowel(1).

